

First roll & glue cylindre, then cut lines 2 cm towards horizontal line



Top spike, roll to cone



connectors - roll slightly smaller than shaft,  
insert half into each shaft's end, then connect .