




Shell Left Protrusion



Outermost Faces




Top Side Faces





Takedown Pin






Pivot Pin






Base Left Protrusion



Right Outside Wall (Rear Section)



Left Outside Wall

Ejection Port Rim Interior

Ejection Port Rim

(Attaches to outside of ejection port, has loops for cover axle)

Barrel Well

Piston Well

Top Wall Lining

Dust Cover
Inner Bump

Ejection
Port Axle

Forward
Assist
Housing













Dust Cover


Forward Assist

Forward Assist Cap


Dust Cover Bottom Rim

Dust Cover Top Rim








Top Rail Base




Top Rail Segments



Brass Deflector





Left Side Bump



Rear Face



Top Rear Tail



PM AR V3A416 Upper Pg.5 (Bolt Carrier Group)

Bolt Face

Bolt Neck

Bolt Carrier

Charging Handle Lengths

Charging Handle Latch

Charging Handle Bottom

Charging Handle Top

Charging Handle Outer Face

Top Attachment

